

Duct sensor PTC



Temperature sensor is used with the diff teperature regulator above.

F29520101 Duct sensor